


creavit[®]
belgium

Manual for our LED-mirrors


LED-lights

Lighting Kelvin range: 3500k - 6500k

Warm light



Cold light




How to switch on/off the LED-light

- 1 Use the on/off button to trigger the LED light.
- 2 To change the color of the light, touch the on/off button for a longer period of time. The light will alternate between cold and warm white.

How to install ROUND mirrors

Requirements:




Drill




Screw driver



Hammer




- 1 Start by drilling a hole in the wall, where you would like to hang the mirror.
- 2 To set the screw correctly, use a plastic plug first. Then insert the screw.
- 3 Be sure to leave 1,5 - 2 cm on the screw to hang the mirror.
- 4 Once you're done, hang up the mirror and make sure it is secure and stable.



How to install RECTANGULAR mirrors

Requirements:




Drill




Screw driver



Hammer




Tape measure




Pencil



powercord place
back of mirror



powercord outer of
mirror



How to use the extra options

Anti-fog:

- 1 If your mirror has an anti-fog function, you can trigger the heating by pressing the anti-fog button.
- 2 Once it is turned on, a heating symbol will be displayed.
- 3 To turn off the anti-fog function, simply press the anti-fog button again.

Setting the clock:

- 1 To set the time on your mirror, first press the anti-fog button until the digits of the clock start flashing.
- 2 Then press the on/off button to adjust the hour and leave it free until the minute digits start flashing.
- 3 Then press the on/off button again to adjust the minutes. Use one touch to adjust per minute.